# **Diesel Maintenance Center**A Central Service Point for Diesel Engines

#### **Fuel Filtration**

Separ Filter fuel / water separator removes 99.9% of water and particulate to ensure clean fuel



In one convenient, mounted station you can clean the diesel fuel, prime the engine and change the oil. Protect your equipment from one, easy point of service. Each feature saves time on maintenance, eliminates spill risks and improves reliability of operation.

The *fuel / water separator* prevents 99.9% of water and particulate from entering the engine system and causing damage to the components. This cleans fuel at a flow capacity of 79 GPH.

The *hand priming pump* purges the air out and moves fuel at the high rate of .85 oz per stroke.

The *oil change pump* drains the used oil to a waste container at 2.5 GPM. Reverse the pump flow with one switch to fill the engine with new oil.

## Multiple maintenance for diesel engines

Single station filters diesel fuel, primes the engine and changes the oil

### Ideal for generators

Permanently install on emergency, standby or primer power

#### Compact design

All components fit on a common base for easy installation and small footprint





